


## The Shaving Shack: Your Shavette blade replacement guide



This razor uses standard (e.g. Merkur, Israeli, Feather, Derby) safety razor double edged blades. **These need to be snapped in half prior to insertion in the holder.** The process is very simple, please see guidelines below.

1. Remove single blade from the outer package but keep blade in it's individual wrapping. Carefully bend length wise until blade snaps.



2. Open Shavette by lifting the hinged cover opening the holder and carefully insert one half of the blade with the blade sitting on the pins as shown below.



3. Close the holder back over the blade and press the cover over firmly, your shavette should now be ready for use.



**Warning.** These notes are for guidance only, by definition razor blades are extremely sharp. Please exercise caution whilst replacing your blades. We cannot accept responsibility for injury sustained whilst replacing one of these blades.